


## Prompt "Wrong user name or password" on the mobile APP



Enter the APP, prompt "Wrong user name or password", please do as follows:

- 1 Click "more" on the right of the device name.
- 2 Click "Edit".
- 3 Enter the correct password and click "complete" to save. (The password as the same NVR login password).

