

How to customize recording mode?

Please right-click mouse navigates to Main Menu > Record Conf.

Period	Time Range	Regular	Detect	Alarm
Period 1	00:00 - 24:00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Period 2	00:00 - 00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Period 3	00:00 - 00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Period 4	00:00 - 00:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

The default record setting is 24 hours (full day) for all channels.

You can customize schedule recording based on your needs.

【Channel】 The channel which you want to setup.

【Length】 The standard length of each segment.

【Mode】 The way you want to record videos.

- ① Schedule: The select channel will only record during the chosen time period.
 - Regular: The system will keep recording during the chosen time period.
 - Dectect: The system will record a video segment when the camera detected movements during the chosen time period.
 - Alarm: The system will record after the external alarm triggers the alarm, because this system cannot connect an external alarm, so this function is not supported.

Example: If you want to record only when the alarm is triggered, please check "Dectect" and uncheck "Regular" and "Alarm".

- ② Manual: The selected channel will record all the time.
- ③ Stop: The selected channel will not record any more.

Attention:

A Default Setting is for Channel 1. If you want to setup the same recording mode for all channels, please select **channel** as "all".

B If you would like to set the recording mode to "Detect", Please make sure that