10. How to setup APP notification and E-mail alert?

When motion detection is triggered, there are 5 types notification: **Mobile reported:** you will get a phone app notification push. **Send E-mail:** you will receive an email alert.

Alarm sound: you will hear siren alarm from camera side.


IPC alarm out: The camera flashes red and blue lights.

We suggest you select t APP alarm so you can have real time responses to what happens.

If you want to set up APP alert, please follow below steps:

1 Make sure the NVR is "Connected" status

Please see the network status at the top of the monitor.



2 Enable alarm function and check "Mobile reported"

Right-click mouse navigates to **Main Menu** --> **Alarm**--> **Intelligent Alert**, enable alarm function and check "Mobile reported".


			Intelligent Alert
Channel	2	Enable	
Human Detect		Face detection	
	Human Detect	t Face detection	
Record			
Mobile reported			
Alarm Sound			
Advanced	Set	Set	
·			
Sensitivity Mide	dle 🔻	Rule Set	

3 Set up APP to allow receiving notifications.

Login in your XMeye Pro APP, tap [Event] in the bottom of your app--->tap [Settings] --->turn on [Allow Notifications]

16:09	S 2: 42	56 🗢 💷	16:09		6 🖬 1 40	1 ⁵⁶ 11
	Event		<	Ala	rm Push	
	home	Settings >	Allo	w Notifications		
	Cloud Storage N	Purchased >				
Ę	Message	>				
Q		e Me				
		1		\equiv	\bigcirc	1

4 Go to "Settings" on your phone and allow the "Xmeye Pro" APP receiving notifications.





() If you want to set up Email alarm, please follow below steps:

Because the free SMTP function of Email is unstable, it is not recommended to use E-mail notification function.

1 Make sure the NVR is "Connected" status.

2 Enable alarm function and check "Send Email"

(1) Right-click mouse navigates to **Main Menu** --> **Alarm**--> **Intelligent Alert**, enable alarm function.

			Intelligent Alert
Channel Human Detect	2 🔻	Enable Face detection	
	Human Detect	Face detection	
Record Mobile reported Alarm Sound			
Advanced	Set	Set	
Sensitivity Midd	lle 🔻	Rule Set	

(2) Enter the advanced interface and check "Send Email"

		Advanced
Period So PostRec 10	etMD Interval [2]S Sec.	ec.
Tour Send Email FTP upload	Snapshot <mark>✓</mark> Write Log □	
IPCAlarmOut 🚺	OutDelay 10 S	ec.
Voice Prompts Alert	area,please leav 💌	

3 Setup Email

Right-click mouse navigates to Main Menu --> Network--> Net service-->E-mail.

EMAIL		
Enable		
SMTP Server	smtp.gmail.com	
Port	465	
Encryption	SSL v	
User Name	ckkcamera@gmail.com	
Password	••••••	
Sender	ckkcamera@gmail.com	
Receiver	ckkcamera@126.com	
Title	Alarm Message	
Test success		
Mail Testing OK Cancel		

How to set up email on NVR, take xxx@gmail.com as example:

Enable E-mail function

SMTP Server: smtp.gmail.com

Port: 465

Encryption type: SSL

User name: xxx@ gmail.com

- Password: password of your mail xxx @ gmail.com(Some mailboxes use authorization codes instead of passwords)
- Sender: xxx@ gmail.com (If you want to set up the email notification, the SMTP of this email should be enabled, how to enable the SMTP function, please kindly Google it because the setting is different between each email provider).

Receiver: The email you want to receive the email alert (you can use the xxx @gmail. com or any other email you want)

Please click "Mail Testing" first before you apply the setting. It reports " Test success"

if the setup is successful.